







► The Package Contents

V1.1

Adapter plate	Base	Riser	Please make sure the contents are in the box. If something is missing or damaged, please contact your Unitech representative.
 × 1	 × 1	 × 1	
"A" : Thumb Screw	"B" : Screw M2 - L10	"C" : Screw M3.5 - L5	"D" : Screw M4 - L10
 × 4	 × 4	 × 2	 × 4

► Operating Instructions

① Pressing down




② Pulling out the pin

(1)



Two Assembly Methods:

A: RT112 or RT112 Windows

B: TB170 Plus



Use screw "A"
(Thumb screw)




(3)

(4)


RT112 or RT112 Windows

Use screw "B" × 4
(Screw M2-L10)






TB170 Plus

Use screw "B" × 4
and "C" × 2
(Screw M2-L10,
Screw M3.5-L5)




Use screw "D" × 4
(Screw M4-L10)







Tilt



Pivot



Lift



Swivel

CAUTION!

To ensure the unit working properly, please keep all connectors away from the contaminants such as dust, grease, mud, and water.

Negligence may cause the unit to lose communication, short circuit, or overheated. If the connector is damaged, please ensure the connector is fully repaired before using the unit to avoid short circuit.



<http://www.ute.com/>