

RP300 Single Slot Charging Cradle



Quick Start Guide

V1.1

► Package

Please make sure the following contents are in the RP300 Single Slot Charging Cradle gift box. If something is missing or damaged, please contact your Unitech representative.

► The Package Contents

- RP300 Single Slot Charging Cradle

► Getting Started

To charge the RP300, please follow these steps:

1. Ensure the cradle is powered on.
2. Place the device in the cradle until it locks in place.

► Product View



- ❶ Power LED of Cradle
- ❷ Device Charging Slot



- ❸ USB-A Charging Port (Option)
- ❹ USB-C Charging Port

► **How to Charge RP300**

Align the POGO pins on the RP300 with the POGO pins on the cradle for charging.



You can charge RP300 with or without a holder

A. With a holder



B. Without a holder



► **LED Indicator Status**



Power LED of Cradle


LED Status	Description
Blue LED	Cradle Power On
LED Off	Cradle Power Off

- Note:**
- 1. To check the charging status of the RP300, please refer to the RP300 Quick Start Guide.
 - 2. The power status of the EA660/EA530 Series is on itself.
 - 3. The RP300 cradle charges the RP300 and the device simultaneously.

► Charging the RP300

We highly recommend using the original adapter. If you use a different adapter, please ensure that you follow the guidelines below before charging:

- Use a PD fast charging adapter.
- Recommended to use 45W Adapter (or up to 45W).
- Support 5V/3A, 9V/2A, and 12V/1.5A segment charging.




► Mounting on a Server Rack

The RP300 Single Slot Charging Cradle can be mounted on a standard 19-inch server rack.

- Secure the screws in the designated holes.



- Align the bottom holes of the RP300 Single Slot Charging Cradle with the corresponding holes on the server rack.



- Push the RP300 Single Slot Charging Cradle backward and ensure it is securely fixed.

WARNING!

There is a risk of fire and burns if the cradle is used improperly.

DO NOT disassemble, crush, puncture, short external contacts, or dispose the cradle in fire or water.

CAUTION!

To ensure the unit working properly, please keep all connectors away from the contaminants such as dust, grease, mud, and water. Negligence may cause the unit to lose communication, short circuit, or overheated. If the connector is damaged, please ensure the connector is fully repaired before using the unit to avoid short circuiting.

DO charge between 20% and 80% to protect your battery.

Avoid full discharges (<0%) or charging all the time (always 100%) to reduce stress on the battery.

EU Importer:

Unique Technology Europe B.V.
Kapitein Hatterasstraat 19, 5015 BB, Tilburg, the Netherlands

Copyright 2026 Unitech Electronics Co., Ltd. All rights reserved.
Unitech is a registered trademark of Unitech Electronics Co., Ltd.



<http://www.ute.com/>